CONSOLIDATED SAFETY RELIEF VALVE
TYPE 1900 - CONVENTIONAL

Part No.	Nomenclature
1	Base
2	Nozzle
3	Adjusting Ring
4	Adjusting Ring Pin
5	Adj. Ring Pin Gasket
6	Disc
7	Disc Retainer
8	Disc Holder
9	Guide
10	Guide Gasket
11	Bonnet
12	Bonnet Gasket
13	Base Stud
14	Stud Nut
15	Spindle
16	Spindle Retainer
17	Spring Washer
18	Spring
19	Adjusting Screw
20	Adjusting Screw Nut
21	Screwed Cap
*22	Bolted Cap
*23	Packed Cap
*24	Plain Cap
*25	Cap Bolt
*26	Cap Set Screw
27	Cap Gasket
*28	Release Nut
*29	Release Locknut
*30	Lever
*31	Lifting Fork
*32	Lever Shaft
*33	Packing
*34	Packing Nut
*35	Top Lever
*36	Drop Lever
40	Eductor Tube
41	Bonnet Vent Plug

* Shown in Figures 38-42 on page 39 of this manual.




FIGURE 1